



Install the wires from each ring to the corresponding holes in the suction tray from A to E (top to bottom) in the order shown in the drawing.

